

4975 State Route 71, Oswego
630-554-3155
1608 W. Church St. (Rt.34), Sandwich
815-786-3155



Safety Information Sheet

Tile Breeze Tile Saw

WARNING! Always wear safety glasses. Do not wear loose clothing, gloves, jewelry that may get caught in moving parts.

WARNING! Never leave tool running unattended—turn off power.

WARNING! Keep children away.

OPERATION:

1. Before powering or starting, check for damage that could prevent this equipment from proper operation or performing its intended function. Check for binding and alignment of moving parts. Check for damaged, broken, or missing parts.

- Verify the On/Off switch is in the OFF position.
- Before connecting the Tile Breeze to a power supply, be sure the voltage, cycle and phase of the job site power source meet the requirements of:
VOLTAGE: 115V
CYCLE: 60HZ
PHASE: 1-PHASE
- An extension power cord that is too small in wire gauge (diameter), or too long in length, will cause the motor to overheat and cause premature failure.
- Do not cover the motor vents as this could lead to motor overheating.
- If the motor becomes overloaded the circuit protector will trip and shut the motor off. If the motor shuts off during sawing, turn the on/off switch to the off position and push the circuit protector reset button the front of the saw frame in. Turn the on/off switch to the on position.

2. Fill the water tank with water through the hole in the table top. The water level should be to the bottom of the hole in the right side of the saw frame.

WARNING! Always feed work into a blade against the direction of rotation. A blade should always be installed such that rotation is in the direction of the arrow imprinted on the side of the blade.

3. Turn the motor switch to the on position. The saw motor should start running. Adjust the blade guard to minimize water spray.

4. For straight cuts, position the tile squarely against the rip guide of the cutting table holding the tile in place with your hands. For larger tile, remove the rip guide and follow a line on the tile.

NOTE: The blade guard support should follow the cut in the tile. If needed, blade guard support can be adjusted by loosening the mounting screws or by bending slightly to align with the cut.

WARNING!

Keep your hands positioned away from the cutting line to prevent contact with the blade.

Keep the saw clean

Drain and clean the water tray frequently while in use and before storage.